



	PART NUMBERS		
	INJECTOR	CARBURETOR	
FLOW SENSOR	1000-004-1(-Knnnnn)(-EPR)	1000-004-4(-Knnnnn)(-EPR)	
TRUE FLOW SENSOR	1000-006-1X SEE NOTE 12.	1000-006-4X SEE NOTE 12.	

NOTES:

- 1. Install INSIGHT FLOW SENSOR, one per engine, TWO per engine for pressure carburetor.
- 2. Use ONLY approved 1/4 NPT fittings for transducer inlet and outlet, installer supplied.
- 3. Use ONLY approved fuel line assemblies.
- 4. Use approved thread sealant. Torque pipe threads to a max of 15 ft. lbs. (180 in. lbs.)
- 5. INSIGHT supplied electrical harness with 3-pin connector, P/N 1000-809.
- 6. A straight length of fuel line upstream from the sensor inlet will improve accuracy by reducing turbulence in the rotor.
- 7. CONFIRM TRANSDUCER CASE IS GROUNDED TO AIRFRAME GROUND BEFORE POWERING UP.
- 8. Mount transducer with NAMEPLATE facing up.
- 9. Confirm all wiring PRIOR to powering up.
- 10. SEE INSTALLATION SCHEMATIC 1000-301 FOR FLOW SENSOR WIRING DETAILS.
- 11. SEE INSTALLATION SCHEMATIC 1000-816 FOR TRUE FLOW SENSOR WIRING DETAILS.
- 12. SPECIFY GPS MANUFACTURE AND MODEL WHEN ORDERING TRUE FLOW SENSOR, BENDIX KING B-FORMAT, APOLLO AND GARMIN Z-FORMAT.
- 13. FLOW SENSOR 30,000 PULSES PER GALLON UNLESS INDICATED BY -Knnnnn.
- 14. FLOW SENSOR DATA SIGNAL 5V UNLESS -EPR, EXTERNAL PULL-UP RESISTOR REQUIRED, SEE WIRING DIAGRAM.



PIN	FUNCTION	WIRE COLOUR
1	COMMON (DO NOT GROUND)	BLACK OR WHITE/BLUE
2	SIGNAL OUT	WHITE
3	10 TO 30 VDC INPUT	RED OR WHITE/ORANGE





© Copyright 1999

FLOW SENSOR AND TRUE FLOW SENSOR MOUNTING DIAGRAM (BRACKET TYPE 1)


Insight Instrument Corporation Box 122, Fort Erie, Ontario L2A 5M6

BOX 122, FORT ERIE, UNTARIO LZA SMIT

IZE | FILE NAME: | DRAWING NO. | DRAW | CKD | QCC

frount 1E | 1000-303 | JUJ | Q2 | Q2

SCALE none DATE June 1/99 SHEET 1 OF 3





	PART NUMBERS	_
	INJECTOR	CARBURETOR
FLOW SENSOR	1000-004-3(-Knnnnn)(-EPR)	1000-004-6(-Knnnnn)(-EPR)
TRUE FLOW SENSOR	1000-006-3X SEE NOTE 12.	1000-006-6X SEE NOTE 12.

NOTE 2,3 TYPICALLY AN 4 TO 1/4" NPT FUEL OUTLET CABLE CONNECTOR FUEL INLET HIGHER THAN INLET NOTE 2.3

NOTES:

- 1. Install INSIGHT FLOW SENSOR, one per engine, TWO per engine for pressure carburetor.
- 2. Use ONLY approved 1/4 NPT fittings for transducer inlet and outlet, installer supplied.
- 3. Use ONLY approved fuel line assemblies.
- 4. Use approved thread sealant. Torque pipe threads to a max of 15 ft. lbs. (180 in. lbs.)
- 5. INSIGHT supplied electrical harness with 3-pin connector, P/N 1000-809.
- 6. A straight length of fuel line upstream from the sensor inlet will improve accuracy by reducing turbulence in the rotor.
- 7. CONFIRM TRANSDUCER CASE IS GROUNDED TO AIRFRAME GROUND BEFORE POWERING UP.
- 8. Mount transducer with NAMEPLATE facing up.
- 9. Confirm all wiring PRIOR to powering up.
- 10. SEE INSTALLATION SCHEMATIC 1000-301 FOR FLOW SENSOR WIRING DETAILS.
- 11. SEE INSTALLATION SCHEMATIC 1000-816 FOR TRUE FLOW SENSOR WIRING DETAILS.
- 12. SPECIFY GPS MANUFACTURE AND MODEL WHEN ORDERING TRUE FLOW SENSOR, BENDIX KING B-FORMAT, APOLLO AND GARMIN Z-FORMAT.
- 13. FLOW SENSOR 30,000 PULSES PER GALLON UNLESS INDICATED BY -Knnnnn.
- 14. FLOW SENSOR DATA SIGNAL 5V UNLESS -EPR, EXTERNAL PULL-UP RESISTOR REQUIRED, SEE WIRING DIAGRAM.
- 15. Transducer self supporting on fuel fittings.







© Copyright 1999


FLOW SENSOR AND TRUE FLOW SENSOR MOUNTING DIAGRAM (BRACKET TYPE 3)

VIEW INTO CONNECTOR

Insight Instrument Corporation Box 122, Fort Erie, Ontario L2A 5M6

fmount3E none


1000-303 DATE June 1/99 3 OF 3



NOTES:

- 1. Install INSIGHT FLOW SENSOR, one per engine, TWO per engine for pressure carburetor.
- 2. Use ONLY approved 1/4 NPT fittings for transducer inlet and outlet, installer supplied. Use appropiate fittings to match airplane fuel lines.
- 3. Use approved thread sealant. Torque pipe threads to a max of 15 ft. lbs. (180 in. lbs.)
- 4. INSIGHT supplied electrical harness with 3-pin connector, P/N 1000-809.
- 5. A straight length of fuel line upstream from the sensor inlet will improve accuracy by reducing turbulance in the rotor.
- 6. Mount on firewall or airframe with NAMEPLATE facing up.
- 7. Installer may drill additional holes in bracket if necessary.
- 8. CONFIRM TRANSDUCER CASE IS GROUNDED TO AIRFRAME GROUND BEFORE POWERING UP.
- 9. Confirm all wiring PRIOR to powering up.
- 10. SEE INSTALLATION SCHEMATIC 1000-301 FOR FLOW SENSOR WIRING DETAILS.
- 11. SEE INSTALLATION SCHEMATIC 1000-816 FOR TRUE FLOW SENSOR WIRING DETAILS.
- 12. SPECIFY GPS MODEL WHEN ORDERING TRUE FLOW SENSOR, B = BENDIX KING, Z = APPOLLO AND GARMIN.
- 13. FLOW SENSOR 30,000 PULSES PER GALLON UNLESS INDICATED BY -Knnnnn.
- 14. FLOW SENSOR DATA SIGNAL 5V UNLESS -EPR, EXTERNAL PULL-UP RESISTOR REQUIRED, SEE WIRING DIAGRAM.

PIN	FUNCTION	WIRE COLOUR
1	COMMON (DO NOT GROUND)	BLACK OR WHITE/BLUE
2	SIGNAL OUT	WHITE
3	10 TO 30 VDC INPUT	RED OR WHITE/ORANGE





FLOW SENSOR AND TRUE FLOW SENSOR MOUNTING DIAGRAM (BRACKET TYPE 2)

Insight Instrument Corporation Box 122, Fort Erie, Ontario L2A 5M6 fmount2E 1000-303 JUT 92 JUT E

none DATE June 1/99 SHEET 2 OF 3